

# DIY MMA *green* BIKE LANE KITS

## Basic Application Overview

1. Add recommended catalyst, based upon ambient pavement temperatures, and supplied aggregate to 3 gallons resin. Mix thoroughly with high-speed drill and appropriate paint mixer.
2. Immediately pour material within masked application area of a prepared, clean surface.
3. Evenly distribute at 17-18 sqft per gallon, or approximately 90 mils build thickness, using a fine tooth rake, concrete rake, squeegee, or notched squeegee.
4. Remove masking materials immediately after distributed. Open to traffic after fully cured; 25-60 min.

## TECH NOTES

### Product Codes:

- MMA Resin - 999660G
- Aggregate - GAG0099-SA-17.5kg
- Catalyst - MC0001

**"No job is too big or too small!"**

